

WE HELP YOU ATTACH THE RIGHT FILE TO YOUR ORDER

In basic customization we print in flexography or screen printing, so your bags can have the design you want on both sides, in a single color and within a limited area that varies depending on the size of your bag. You can check the size of this area in the template tab found next to the description of each product.

- ATTACHED FILE

You can send us your design in any type of format as long as it has good quality, preferably outlined or vectorized. The optimal file resolution is 250 to 300 dpi.



Non-vector logo
(If enlarged, it loses resolution)



Vector logo
(Can be enlarged without losing resolution)

- DESIGN COLORS

- 1.- We have a wide variety of predefined colors; however, if the color you want is not among them, you can provide us with its Pantone U reference and we will try to match it as closely as possible.*
- 2.- Due to the material of the bag and the base color, there may be a slight color variation.*

- TEMPLATE

- 1.- Download the template corresponding to the product you want to customize. You will find it in the TEMPLATES section next to the product description.*
- 2.- Insert your design within the predefined area in the design table.*
- 3.- Remember to outline or convert fonts to curves.*
- 4.- Save the file. Before saving, make sure not to change the design scale or reduce the template we provide.*

- INFORMATION ABOUT PRINTING IN BASIC CUSTOMIZATION

The design must not contain solid fills, screens, gradients, fades, halftones or transparencies and must be vector-based in a single color. Keep in mind not to use very small fonts in the text; we recommend sizes greater than 12 pt.



No screens, no gradients



No solid fills or reversed text